Liebherr® hydraulic backhoe

Mission Zero Towards zero emissions by 2030

Replacement parts identification for models R994™ | R994B™ | R9350™ | R996™ | R996B™ | R9800™



Pins and bushings

- A Link and bucket
- B Link and link
- C Link and bucket cylinder
- D Bucket and stick
- E Link and stick
- F Stick and stick cylinder
- G Boom and stick
- H Boom and hoist cylinder
- I Bucket cylinder and stick
- J Boom and stick cylinder
- K Frame and hoist cylinder
- L Boom and frame

Undercarriage components

M

Idler

N



Drive tumbler

O

Upper roller

P

Lower roller

Q

Track pad



FLSmidth Inc. - Pekin Operations
Pekin, IL 61554 USA

24/7 Hotline
+1 309 202 8300

FLSmidth A/S
2500 Valby
Denmark

www.flsmidth.com

All brand names, model names or marks are owned by their respective manufacturers. FLSmidth has no affiliation with the original equipment manufacturer. These terms are used for identification purposes only and are not intended to indicate affiliation with or approval by the OEM. All parts are manufactured by, for and warranted by FLSmidth and are not manufactured by, purchased from or warranted by the original equipment manufacturer.

FLS